

Installation Instructions



Pro-Damper Kit – # 35125.840

2011-14 Ford Mustang/Mustang GT, Incl. Conv, 3.7L V6 and 5.0L V8

Kit Contents	Description	Part Number	Qty
	Front Damper	35125.8001	2
	Rear Damper	35125.8002	2
	Rear Hardware Kit	35125.8002HK	2
	Front Bumpstop	BS770034	2
	Front Dustboot	BS770041	2
	Information Kit	EPAK	1

NOTES: **Read All Instructions Before Beginning Installation**

1. Park vehicle on level surface and set emergency brake. Raise and support the vehicle with safety stands. Refer to factory manual for proper location of safety stands.
2. Power washing your chassis will make the installation cleaner.
 - **NOTE:** Never work on or under a vehicle unless it is properly supported by safety stands.

Additional Eibach Components Available For Your Cars

Eibach Kits	Part Number	Description /	Front	Rear
Pro-Kit	35125.140	Performance Handling	“Call”	“Call”
Sportline	4.12535	Performance Handling	“Call”	“Call”
Anti-Roll Kit (Adjustable front and non-adjustable rear bar)	35125.320	Performance Handling	36mm	25mm
Anti-Roll Kit (optional) (Adjustable front and rear bar)	35129.320	Performance Handling	36mm	25mm

