

# OPEN FIRST!!

**ENERGY**  
**SUSPENSION** 

## Parts List for Master set # 3-18128 01-06 Chevy 2500 HD 2wd/4wd

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle. Wheel alignment is almost always disturbed when suspension components are removed or replaced. It is recommended that you have the alignment checked on your vehicle at a qualified alignment shop. Energy Suspension recommends that you read over all the installation instructions and check all P/N's and quantities in the parts list before you start. Call customer service if the parts in your kit do not match this parts list. Prior to installation, make sure that your car is in excellent mechanical condition and that there are no suspension or steering related problems. This part has been designed to work only with a car that is in good state of repair. No matter how carefully we design our parts, this is one area we have no control over and cannot be held responsible.

### Parts list:

Energy Suspension recommends that you **read over all the installation instructions and parts list *before you start.***

#### Front control arm bushing set: 3.3185

- 4 3424 Upper bushings
- 2 3375 Front lower bushings
- 2 3376 Rear lower bushings
- 2 15.10.413.39 Sleeves (1.000x0.640x2.950)
- 2 15.10.414.39 Sleeves (1.000x0.640x3.860)
- 4 15.07.25.40 lock nut for lower control arm bolts (16mm X 2.00mm crush lock nut)
- 1 17019 Instruction sheet

#### Front sway bar bushing set: 3.5213

- 2 5356 36mm Front sway bar bushings
- 2 15.12.20.39 Sway bar brackets
- 4 15.03.69.39 Washers
- 2 15.12.100.\* Endlink assembly
- 1 17479 Instalation Instructions

#### Rear leaf spring bushing set: 3.2141

- 4 2509 Front position bushing
- 4 2511 Rear position bushing
- 4 2512 Shackle position bushing'
- 2 15.10.483.39 Sleeves (1.000x.640x3.000)
- 4 15.10.276.39 Sleeves (.875x.563x3.000)
- 1 17040 Instruction Sheet

#### Body mount set: 3.4150

- 8 4200 Upper bushings
- 8 4201 Lower bushings
- 8 15.03.11.39 Washer (3.000x9/16)

#### Misc:

- 1 17145 Instruction Sheet



2001-06 Chevy  
2500 Heavy Duty 2wd/4wd