

# Installation instructions

For set # 3.4171

1968-1972 CHEVY CHEVELLE

SS Big Block

Supplement Body Mounts



\*Some Big Block Chevilles & El Caminos have a top & bottom mount in positions 2 or 4 and some had both. This set is a supplement to set 3.4170 and does not include mounts for positions 1, 3, 5, 6, 7 and 8.

## Parts List:

- 4 - 4287 upper mount
  - 4 - 4288 lower mount
  - 4 - 15.02.30.39 inner washer/sleeve
  - 4 - 15.05.54.39 7/16-14 x 2-1/2 bolt
  - 4 - 15.03.09.39 2 x 7/17 x 1/8 washer
  - 2 - 15P0704342 7/16-14 flange nut
- Flange nut, if needed is to replace the factory square captive nut at position 2.

