

Installation Instructions

For set # 4.1136
1966-72 Ford Mustang
Transmission Mount Kit
Patent# 5551661



© 2012 Energy Suspension. All rights reserved.
May not be reproduced, in any form, or by any means,
without the written consent of Energy Suspension.

Installation Procedure

- Using a floor or transmission jack, support transmission to secure its position at stock height
- Remove bolts securing the O.E. transmission mount to the cross member
- Lift transmission slightly in order to take pressure off of cross member. Remove cross member and emergency brake linkage assembly
- Unbolt O.E. transmission mount and remove (Pic 1)
- Orientate the new polyurethane transmission mount and backing plate so that mounting holes align and the Energy Suspension logo is facing the rear of the vehicle (Pic 2). Secure transmission mount using the provided hardware and tighten to factory recommended torque
- Install cross member and emergency brake linkage assembly
- Secure the polyurethane transmission mount to the cross member using the provided hardware and tighten to factory recommended torque (Pic 3)

Parts List

Qty.	Part Number	Description
1	1287	Trans Mount
1	15.08.35.39	Backing Plate
4	15.03.42.39	Flat Washer
2	15.03.48.39	Lock Washer
4	15.05.30.39	Bolt 7/16-14

