

Installation instructions

For set # 4.8101
E-Series Endlink Bushings



It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

- 1) Remove sway bar and O.E.M. shell from I-Beam.
- 2) De-burr sharp edges from both sides of axle.
- 3) To help installation, grease leading edge of bushing then install bushing into axle using a C-clamp and 2 wood blocks or metal washers.
- 4) Grease I.D. of bushing and O.D. of sway bar.
- 5) Reinstall sway bar.

Learn more about suspension parts on our website.