



Instructions for set # 5-1102 (Note; Customer must **reuse** original **hardware** and factory **sleeve**). Remove center console to access shifter mounting plate. Remove factory rubber bushings and discard, save inner metal sleeve and hardware as it will need to be reused. Install factory metal sleeve into polyurethane bushing #1101 and install onto shifter plate from the top. Install polyurethane bushing ring #1102 onto protruding nipple of bushing #1101 under shifter plate. Install all remaining bushings and hardware and tighten all fasteners.

Learn more about suspension parts on our website.