INSTRUCTION SHEET FOR SET #5.1111 Read this instruction sheet thoroughly before initiating any work!

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's Polyurethane.

USPENSI\\ N_®

Use caution when handling clips, brackets, etc. They are made of plastic and are easy to break. Be delicate, they are the only thing holding most of the panels together.

PARTS LIST:

- 4 1214 Lower Shifter Bushing
- 4 1215 Upper Shifter Bushing
- 1 17466 Instruction Sheet




























First, place the **#1214** lower bushing in from the bottom. Then push in the metal sleeve from the bottom. Once the other positions are done, set bracket back down and place the #1215 on top. Place the bolt back in and start it. Repeat for the other three positions and then tighten all four bolts to factory specifications.

