

# OPEN FIRST!!

## Parts list for Master set # 16.18105 1994-01 Acura Integra (Except Type "R")



It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

### Transmission shifter stabilizer bushing set: 16.1101

- 1 - 1033 (mounts near shifter)
- 1 - 1032 (mounts at the transmission)
- 1 - 17161 installation instructions

### Front end control arm bushing set: 16.3105

- 2 - 3285 lower control arm pivot bushing(rear position)
- 2 - 15.10.246.39 (1.00"O.D. x .718"l.D. x 2.277" sleeve)
- 4 - 2274 lower control arm pivot bushing(front position)
- 2 - 15.10.245.39 (.750"O.D. x .480"l.D. x 1.960" sleeve)
- 4 - 3284 upper control arm pivot bushing
- 4 - 15.10.244.39 (.750"O.D. x .406"l.D. x 1.577" sleeve)
- 1 - 17141 installation instructions

### Rear end control arm bushing set: 16.3109

- 8 - 2301 lower control arm pivot bushing
- 4 - 3288 lower control arm pivot bushing
- 4 - 15.10.279.39 (.750"O.D. x .406"l.D. x 1.960" sleeve)
- 1 - 17140 installation instructions

### Front shock bushing set: 16.8102 (press out bushing and shell)

- 4 - 2272 lower control arm shock mount
- 4 - 8096 upper shock mount(use O.E. sleeve)
- 2 - 15.10.245.39 (.750"O.D. x .480"l.D. x 1.960" sleeve)
- 1 - 17162 installation instruction

### Rear shock bushing set: 16.8103 (press out bushing and shell)

- 4 - 2270 lower control arm shock mount
- 4 - 8096 upper shock mount(use O.E. sleeve)
- 2 - 15.10.279.39 (.750"O.D. x .406"l.D. x 1.960" sleeve)
- 1 - 17163 installation instruction

### Rack and pinion bushing set: 16.10102

- 4 - 10022 drivers side (all models)
- 1 - 10024 passenger side (power steering only.  
bushing not available for other models)
- 1 - 17153 installation instructions

### Parts list continued:

#### Front endlink set: 16.8104

(GSR will use 1/2 of the set)

- 8 - 8072 endlink bushing
- 2 - 15.10.226.39 (.562" O.D. x .375"l.D. x .400" sleeve)
- 8 - 15.03.03.40 cupped washer
- 2 - 15.05.28.39 (3/8"-16 x 3-3/4" bolt)
- 2 - 15.07.01.40 (3/8"-16 nylock nut)
- 1 - 17039 installation instructions
- 1 - 17236 installation instructions

#### Front balljoint boot set:

- 2 - 13001 (lower balljoint)
- 2 - 13003 (upper balljoint)

#### Tie rod boot set:

- 2 - 13003 tie rod boots

### Additional parts available for your vehicle:

Rear Trailing Arm bushing set: 16.7106

#### Front anti-swaybar bushing set (does not include endlinks):

Bar Dia.	Set #
24mm	16-5104
22mm	16-5108
21mm	16-5105

#### Rear anti-swaybar bushing set (does not include endlinks):

Bar Dia.	Set #
14mm	16-5106
13mm	16-5107

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.