

OPEN FIRST!!

ENERGY SUSPENSION®

Parts list for Master set # 16.18107 1994-97 Honda Accord

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list:

Energy Suspension recommends that you **read over all the installation instructions** and check all P/N's and quantities in the parts list **before you start**. Call customer service at 949-361-3935 if the parts in your kit do not match this parts list.

Front end control arm bushing set:16.3106

- 4 - 2294 lower control arm bushing outer.
- 2 - 3289 lower control arm bushing center.
- 2 - 15.10.224.39 lower control arm sleeve.
(3/4"O.D. x 12mm I.D. x 2.225")
- 8 - 2280 upper control arm bushing.
- 4 - 15.10.244.39 upper control arm sleeve.
(3/4"O.D. x 10mm I.D. x 1.577")
- 1 - 17152 installation instructions.

Front strut rod set:16.7103

- 2 - 7096 rear position.
- 2 - 7097 front position.

Front shock bushing set:16.8106

- 4 - 8096 upper shock bushing.
- 4 - 2295 lower shock bushing.
- 2 - 15.10.302.39 lower shock sleeve.
(3/4"O.D. x 12mm I.D. x 2.040")
- 1 - 17162 installation instructions.

Front end link set:16.8105

- 8 - 8098 end link bushing.
- 2 - 15.10.200.39 sleeve.
(1/2"O.D. x 3/8" I.D. x .400")
- 2 - 15.05.28.39 (3/8" - 16 x 3-3/4") bolt.
- 2 - 15.07.01.40 (3/8" - 16) locknut.
- 8 - 15.03.29.39 (1-1/2"O.D. x 3/8" I.D.) cup washer.

17226

Parts list continued:

Front balljoint boot set:16.13102 upper & lower

- 2 - 13003 balljoint boot.
- 2 - 13005 balljoint boot.

Front tie-rod boot set:9.13103

- 2 - 13003 tie-rod boot.

Front spring pad set:16.6101

- 2 - 6133 upper spring pad.

Grease: 1 - 9.11101 grease tubs.

Additional parts available for your vehicle:

**Front anti-swaybar bushing set (does not
include endlinks):**

Bar Dia.	Set #
25mm	9-5129
22mm	9-5126

**Rear anti-swaybar bushing set (does not
include endlinks):**

Bar Dia.	Set #
15mm	16-5117
14mm	16-5116

**Motor mount insert set:
(manual trans only)**
16-1108

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

B.O.M. For Master set # 16.18107

Parts list:

Front end control arm bushing set:16.3106

- 4 - 2294
- 2 - 3289
- 2 - 15.10.224.39 (3/4"O.D. x 12mm I.D. x 2.225")
- 8 - 2280
- 4 - 15.10.244.39 (3/4"O.D. x 10mm I.D. x 1.577")
- 1 - 17152 installation instructions.

Front strut rod set:16.7103

- 2 - 7096
- 2 - 7097

Front shock bushing set:16.8106

- 4 - 8096
- 4 - 2295
- 2 - 15.10.302.39 (3/4"O.D. x 12mm I.D. x 2.040")
- 1 - 17162 installation instructions.

Front end link set:16.8105

- 8 - 8098
- 2 - 15.10.200.39 (1/2"O.D. x 3/8" I.D. x .400")
- 2 - 15.05.28.39 (3/8" - 16 x 3-3/4" bolt).
- 2 - 15.07.01.40 (3/8" - 16 locknut).
- 8 - 15.03.29.39 (1-1/2"O.D. x 3/8" I.D. cup washer).

Parts list continued:

Front balljoint boot set:16.13102

- 2 - 13003
- 2 - 13005

Front tie-rod boot set:9.13103

- 2 - 13003

Front spring pad set:16.6101

- 2 - 6133

Grease:

- 1 - 9.11101

Parts list"

- 1 - 17226

Packaging Instructions


All sleeves and instructions for each set must be packaged together in individual bags.

Fold the parts list # 17226 so the

"OPEN FIRST!!

On the Master set 16.18107"
Is clearly visible when packaged on skin packing card.