

# OPEN FIRST!!



## Parts list for Master set # 4.18112

### Front end control arm bushing set:

- 2 - 3267 lower control arm pivot bushing, front position
- 2 - "O" shell (use with 3267 bushing)
- 2 - 15.10.34.39 (7/8"O.D. x 5/8"I.D. x 3.00 sleeve )
- 2 - 3270 lower control arm pivot bushing, rear position
- 2 - 15.10.33.39 (7/8"O.D. X 5/8"I.D. X 3.187 sleeve)
- NOTE: MUST REUSE REAR POSITION O.E. SHELL. DO NOT REMOVE!
- 1 - 17019 installation instructions

### Rear end control arm bushing set:

- 2 - 3027 lower control arm pivot bushing, axle end
- 2 - 3076 lower control arm pivot bushing body end (oval shape)
- 2 - 3101 thrust washer use with 3027 bushing
- 2 - 3109 thrust washer use with 3076 bushing
- 4 - 15.10.171.39 (3/4"O.D. x .480"I.D. x 2.900 sleeve)lower arms
- 2 - 3028 upper control arm pivot bushing, body end
- 2 - 3029 upper control arm pivot bushing axle end
- 2 - 3098 thrust washer use with 3029 bushing
- 2 - 3099 thrust washer use with 3028 bushing
- 4 - 15.10.170.39 (3/4"O.D. x .480"I.D. x 2.400 sleeve)upper arms
- 1 - 17041 installation instructions
- use 17019 installation instructions

### Front spring isolator set:

- 2 - 6070 upper
- 2 - 6071 lower

### Rear spring isolator set:

- 2 - 6053 upper
- 2 - 6054 lower

### Front McPherson strut tower bushing set:

- 2 - 2215 bottom bushing
- 2 - 2214 top bushing
- 2 - 15.10.51.39 (7/8"O.D. x 5/8"I.D. x 2.125 sleeve)
- 1 - 17275 installation instructions

### Parts list continued:

#### Front Swaybar endlink set :

- 8 - 4806 endlink grommets
- 2 - 15.10.75.39 (9/16"O.D. x 3/8"I.D. x 3.562" sleeve)
- 8 - 15.03.01.39 (cupped washer)
- 2 - 15.05.05.39 (3/8"-16 x 7.5" bolt)
- 2 - 15.07.01.40 (3/8"-16 nut)

#### Rack and pinion bushing set for stock height to 1-1/4" lowered vehicles):

- 4 - 10003 bushing
- 1 - 17094 installation instructions

#### Offset rack and pinion bushing set for vehicles lowered more than 1-1/4": (these offset rack bushings help correct the bump steer caused by lowering the vehicle):

- 4 - 10020 bushing
- use 17094 installation instructions

#### Tie-rod boot set:

- 2 - 13001 tie-rod boot
- 2 - 13009 ball joint boot

#### Grease:

#### Additional parts available for your vehicle:

Transmission mount set # 4-1104

1979-96 Front anti-swaybar bushing set:

Does not include endlinks

Bar Dia.	Set #
7/8"	4-5113
15/16"	4-5112
1"	4-5111
1-1/16"	4-5110
1-1/8"	4-5109
30mm	4-5135
1-1/4"	4-5108
1-5/16"	4-5101
1-3/8"	4-5136

# 17221