

General Purpose Control Arm Bushing Instructions

(Diagram may not represent your exact bushing assembly)



If your new bushing kit does not have new shells and/or sleeves, you must reuse the original shells and /or sleeves.

Embossed washers (when used) must be completely seated inside of sleeve before reinstalling the control arm. A vise can be used to compress embossed washers into the sleeve I.D. This will seat the washers properly.

For ease of installation of bushing and sleeve (or new shell when supplied) disassemble new bushing unit. (When supplied install shell first). Grease I.D. of shell. Grease bushing and install in shell. Grease sleeve and install in bushing.

Note: When a control arm cross shaft is used, it must be in position before installing bushings and/or new shells. All washers, or spacers on shaft must be reused, and installed in correct location before installing new bushings.

