

Installation instructions

For set # 4.8101
E-Series Endlink Bushings



- 1) Remove sway bar and O.E.M. shell from I-Beam.
- 2) De-burr sharp edges from both sides of axle.
- 3) To help installation, grease leading edge of bushing then install bushing into axle using a C-clamp and 2 wood blocks or metal washers.
- 4) Grease I.D. of bushing and O.D. of sway bar.
- 5) Reinstall sway bar.

17128

[View other performance suspension parts](#) made [by Energy Suspension](#) on our website.