OPEN FIRST!!

Parts list for Master set # 5.18106 95-99 Neon

Front end control arm bushing set: 5.3116

- 2 2263 control arm bushings frt. pos. frt. side
- 2 3279 control arm bushings frt. pos. rr. side
- 2 15.10.296.39 (.813" x .562" x 2.435" sleeve)
- 2 3277 control arm bushings rear pos. (vert.) 2 15.10.83.39 (.875" x .562" x 2.030" sleeve)
- 1 17135 installation instructions

Rear end control arm bushing set: 5.3117

12 - 2261 bushings (spindle end)

- 4 2260 bushings (body end)
- 6 15.10.297.39 (.688" x .480" x 1.452" sleeve)
- 8 15.03.57.39 (1-1/4" O.D. X 1/2"I.D. Washer)
- 1 17136 installation instructions

Rear strut rod set (reuse all original hardware): 5.7110

8 - 7094 strut rod bushings

Front Swaybar bushing set: 5.5120

2 - 5318 (22mm) swaybar pivot bushings

Front Swaybar bushing set: 5.5144

2 - 5497 (20mm) swaybar pivot bushings

Front endlink set: 5.8101

- 2 15.10.56.39 (.562" x .375" x 1.000" sleeve)
- 8 8072 endlink bushings
- 8 15.03.03.40s cupped washer
- 2 15.05.28.39 (3/8-16 x 3-3/4" bolt) 2 15.07.01.40 (3/8-16 nylock nut)
- 1 17039 installation instructions

Rear Swaybar bushing set: 5.5121

2 - 5319 (16mm) swaybar pivot bushings

Rear endlink set: 5.8102

- 4 8005 end link bushings
- 4 15.10.250.39 (.625" x 10mm x 1.210" sleeve)
- 1 17039 installation instructions



It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Tie rod boot set: 9.13103 2 - 13003 tie rod boots

Grease:

2 - 9.11113 grease tubs