

# Installation instructions

For set # 5.3141  
LX REAR SET



It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

## Parts list:

12-2853 RR TENSION LK	4-2855 SPRING LINK	12-15.07.27.40 FLANGED LOCKNUT
4-2854 CAMBER LINK	2-15.10.632.39 TOE LINK OUTER	4-15.03.05.39 WASHER
4-2851 TOE LINK INNER	2-15.10.633.39 TO LINK INNER	2-15.05.89.40 BOLT
4-2852 TOE LINK OUTER	6-15.10.520.39 CAMBER TENSION ARM	1-17556 INSTRUCTIONS
4-2874 COMPRESSION LINK	2-15.10.618.39 COMPRESSION LINK FWD	3-9.11113 GREASE
	2-15.10.518.39 OUTER CAMBER	

