

Parts list for Master set # 7-18102 1974-78 Datsun 260Z & 280Z

Front radius/strut arm bushing set: 7.7102

- 4 - 7020 bushings
- 2 - 15.10.65.39 (.688"O.D. x .500" I.D. x 2.000" sleeve)

Front control arm bushing set: 7.3106

- 2 - 3060 bushings
- 2 - 15.10.55.39 (.750"O.D. x .563" I.D. x 2.450" sleeve)
- 2 - 3061 bushings
- 1 - 17019 installation instructions
- 2 - 9.11108 grease

Steering coupler set: 7.16101

- 1 - 16001 bushings
- 4 - 15.10.162.39 (.500"O.D. x .375" I.D. x .880" sleeve)
- 4 - 15.10.240.39 (.500"O.D. x .313" I.D. x .875" sleeve)

Rack and pinion bushing set: 7.10102

- 1 - 10018.1(top drivers side)
- 1 - 10018.2(bottom drivers side)
- 1 - 10019.1(top passenger side)
- 1 - 10019.2(bottom passenger side)
- 1 - 17077 installation instructions

Rear control arm bushing set: 7.3104

- 8 - 3062 bushings (hub end)
- 4 - 15.10.70.39 (.750"O.D. x .630" I.D. x 1.830" sleeve)
- 4 - 3078 bushings (inner rear position)
- 2 - 15.10.49.39 (1.187"O.D. x 1.005" I.D. x 2.450" sleeve)
- 4 - 3077 bushings (inner front position)
- 2 - 15.10.95.39 (1.187"O.D. x 1.005" I.D. x 2.062" sleeve)
- 1 - 17019 installation instructions
- 2 - 9.11108 grease

Rear mustache bar bushing set: 7.1102

- Must reuse existing outer metal shell
- 4 - 1006 bushing
 - 2 - 15.10.67.39 (.875"O.D. x .625" I.D. x 2.600" sleeve)
 - 4 - 15.03.24.39 (2-1/2" O.D. x 5/8" I.D. Washer)
 - 1 - 17064 installation instructions
 - 1 - 9.11108 grease

It is recommended that if you are unfamiliar with this type of work that you refer to a qualified service center specializing in this type of work. It is also recommended that if you choose to do this work yourself that a factory service manual be obtained for the proper procedures pertaining to removal, replacement and proper torque specifications for your vehicle. This instruction set is intended as a guideline for the safe installation of Energy Suspension's polyurethane bushings, once you have removed the factory components from your vehicle.

Parts list continued:

Front endlink set: 9.8120

- 8 - 4806 endlink grommets
- 8 - 15.03.01.39 (cupped washers)
- 2 - 15.10.22.39(.563"O.D.x.375" I.D.x1.650" sleeve)
- 2 - 15.05.02.39 (3/8"-16 x 5-1/2" bolt)
- 2 - 15.07.01.40 (3/8"-16 nut)

Rear swaybar frame bushing (20mm) and endlink set: 7.5110 & 9.8120

- 2 - 5254 (20mm)bushings (fits factory bracket)
- 8 - 4806 endlink grommets
- 8 - 15.03.01.39 (cupped washers)
- 2 - 15.10.22.39(.563"O.D.x.375" I.D.x1.650" sleeve)
- 2 - 15.05.02.39 (3/8"-16 x 5-1/2" bolt)
- 2 - 15.07.01.40 (3/8"-16 nut)
- 1 - 17039 installation instructions
- 1 - 9.11108 grease

Front and rear bump stop set: 7.6104

- 4 - 6016 bushings

Transmission crossmember mount bushing set: 7.1101

- 4 - 4066 bushings
- 2 - 15.10.131.39 (.875"O.D. x .625" I.D. x 1.560" sleeve)

Tie rod boots: 9.13103

- 2 - 13003 tie rod boots

Additional parts available for

Swaybar and endlink bushings

Front frame bushings	Bar dia.	Set #
	16mm	7-5112
	18mm	7-5101
	20mm	7-5102

Please refer to our newest catalog for more information on custom applications including bump stops, shock bushings, universal mounts, tie rod boots, ball joint boots, transmission mounts, Formula 5 Prelube etc. Please ask to see our catalog at your place of purchase.

17202