

Installation instructions

For set # 3.1147 Chrome

For set # 3.1148 Gold

LS1 Engine adapter kit



Parts list: 3.1147 Chrome

- 2 - 1106 (short and wide engine mount).
- 1 - 15.06.56.41 (adapter plate passenger side).
- 1 - 15.06.57.41 (adapter plate driver side).
- 2 - 15.05.85.41 (M10 x 1.5mm x 25mm socket head cap screw).
- 6 - 15.05.74.41 (M10 x 1.5mm x 35mm bolt).
- 4 - 15.05.36.41 (3/8-16 x 1.00" bolt).
- 10 - 15.03.122.41 (19mm O.D. x 10mm I.D. x .2mm flat washer).
- 1 - 17539 (this instruction sheet).

Parts list: 3.1148 Gold

- 2 - 1108 (short and wide engine mount).
- 1 - 15.06.56.39 (adapter plate passenger side).
- 1 - 15.06.57.39 (adapter plate driver side).
- 2 - 15.05.85.39 (M10 x 1.5mm x 25mm socket head cap screw).
- 6 - 15.05.74.39 (M10 x 1.5mm x 35mm bolt).
- 4 - 15.05.36.39 (3/8-16 x 1.00" bolt).
- 10 - 15.03.122.39 (19mm O.D. x 10mm I.D. x 2mm flat washer).
- 1 - 17539 (this instruction sheet).

