

INSTALLATION GUIDE

TOYOTA TACOMA (2016+)





Included Hardware:

- (4) 1/2" Bolts
- (8) 1/2" Washers
- (8) 1/2" Locking Nuts
- (12) 3/8" Bolts
- (12) 3/8" Locking Nuts
- (24) 3/8" Washers

Tools:

- 1/2" wrench and socket
- 3/8" Wrench and socket
- Drill Tool (required)
- Dremel (recommended)

Skill Level:

3/5 stars (Professional install recommended)

Pre-Installation Preparations

Remove plastic cap on frame to expose bolts on the driver side only.



Bracket Install

Remove bracket from backside of frame and move out of the way. Remove bracket from front side frame and push out of the way. Then place mounting bracket as shown in picture and tighten into place



Mark for Drilling

Set rocker guard into place, marking bolts where to drill as shown in photo. Once completed, drill required holes.



Placing Bolts and washers

Replace previously removed brackets and leave everything loose.



Rock Guard Placement

Begin tightening it down, making sure placement is correct and secure in place. Your done!

