



Installation Instructions

2015 Chevy and GMC HD Rear Bumper

Product Number: E3050
Application: 2015+ Chevy and GMC HD Trucks

SAFETY

Your safety and the safety of others is very important.

- In order to help you make informed decisions about safety, we have provided installation instructions and other information.
- These instructions alert you to potential hazards that could hurt you or others.
- Please do a job safety analysis before each task to identify potential hazards for your situation and remove/protect against them.
- You must use your own good judgment, and take your time.

Read and understand all safety precautions and instructions before installing this product.

THIS PRODUCT IS FOR OFFROAD USE ONLY. ALL LIABILITY FOR INSTALLATION AND USE RESTS WITH THE OWNER.

CARELESS INSTALLATION AND OPERATION CAN RESULT IN SERIOUS INJURY OR EQUIPMENT DAMAGE.

IF REPLACING A SENSOR BUMPER, SENSORS' FIELD OF VIEW WILL BE ALTERED WITH USE OF THE REPLACEMENT BUMPER.

Injury hazard

Failure to observe these instructions could lead to severe injury or death.

- Always** remove jewelry and wear eye protection.
- Always** use extreme caution when jacking up a vehicle for work. Set emergency brake and use tire blocks. Locate and use the vehicle manufacturers designated lifting points. Use jack stands.
- Always** use appropriate and adequate care in lifting components into place.
- Always** insure components will remain secure during installation and operation.
- Always** wear safety glasses when installing this kit. A drilling operation will cause flying metal chips. Flying chips can cause serious eye injury.
- Always** use extreme caution when drilling on a vehicle. Thoroughly inspect the area to be drilled (on both sides of material) prior to drilling, and relocate any objects that may be damaged.
- Always** use extreme caution when cutting and trimming during fitting.
- Always** tighten all nuts and bolts securely per installation instructions.
- Always** route electrical cables carefully. Avoid moving parts, components that become hot and rough or sharp edges.
- Always** insulate and protect all exposed wiring and electrical terminals.
- Always** perform regular inspections and maintenance on mounts and related hardware.



Installation Instructions

2015 Chevy and GMC HD Rear Bumper

Product Number: E3050
Application: 2015+ Chevy and GMC HD Trucks

I. Parts List

- E3050 rear replacement bumper with mounting brackets
- 50029-HW fastener kit
- Instruction Manual

II. Tools Required

- Socket Wrench with Extensions
- 3/4", 13mm, 15mm, 18mm, & 21mm Sockets
- 3/4", 13mm, 15mm, 18mm, & 21mm Box End Wrench



Installation Instructions

2015 Chevy and GMC HD Rear Bumper

Product Number: E3050
Application: 2015+ Chevy and GMC HD Trucks

III. Removal of Stock Bumper

1. Remove license plate, and OEM license plate lights. Disconnect trailer receptacle. If equipped, unplug back-up sensor harness.
2. Remove the two bolts attaching the stock bumper to the factory trailer hitch using a 13mm wrench.



Figure 1

3. Remove the six bolts (three per side) attaching the stock bumper to the chassis using a 21mm wrench. Remove the remaining two bolts (circled in red) with a 15mm wrench.



Figure 2

Installation Instructions

2015 Chevy and GMC HD Rear Bumper

Product Number: E3050

Application: 2015+ Chevy and GMC HD Trucks



Figure 3

4. Loosen the bolts attaching the bed to the truck using an 18mm wrench.
5. Remove the OEM sensors from their housings (4 in total).
6. Remove OEM bumper by lifting the bed from the truck and pulling the bumper rearward away from the truck.
7. Remove OEM Spare Tire Access Cover and Trailer Plug from the OEM bumper. Set aside for reinstallation.
8. Remove the sensor housings from the stock bumper by pressing in on the four housing tabs and pushing it out of the bumper.

Installation Instructions

2015 Chevy and GMC HD Rear Bumper

Product Number: E3050

Application: 2015+ Chevy and GMC HD Trucks

IV. Installation

1. **FOR SENSOR BUMPER INSTALLATION ONLY:** Place the OEM sensor housings into your Fab Fours Vengeance Plate Bumper. **DO NOT EPOXY AT THIS TIME.**

Due to the angled design of the clips, Fab Fours recommends that you angle the sensors upwards so that the sensors don't read the ground. You will need to test the sensors in this configuration after installing the bumper.

2. Replace OEM bumper with the Fab Fours Vengeance Plate Bumper. First, reattach the trailer hitch to the frame using the provided 1/2"x1" bolts. Then, use the 1/2"x1 1/2" long fasteners and a 3/4" wrench to fasten the bumper mounts to the frame rail in the OEM mounting locations. Do not fully tighten.
3. Level and align the bumper in relation to the truck bed. Fully tighten all fasteners.
4. Slowly lower the tailgate to ensure there will be no interference. If required, loosen the frame/bumper bolts and adjust alignment of the bumper.
5. Install trailer plug receptacle. The stock plug receptacle must be drilled with a 7/32 drill bit (1/4 is acceptable) using the shown impressions in the receptacle as guides. Attach with the provided #8 hardware.



Figure 5

Installation Instructions

2015 Chevy and GMC HD Rear Bumper

Product Number: E3050

Application: 2015+ Chevy and GMC HD Trucks



Figure 6

6. Reinstall license plate with provided plastic inserts
7. Prep the area shown below and attach the red LED light strip in the location shown. Wire as desired.



8. Secure all loose wiring and harnesses to the frame or bumper with zip ties.

Installation Instructions

2015 Chevy and GMC HD Rear Bumper

Product Number: E3050

Application: 2015+ Chevy and GMC HD Trucks

9. **FOR SENSOR BUMPER INSTALLATION ONLY:** Install the sensor harness back into the housing clips and plug the OEM sensor harness into the truck. Test the sensors to ensure that the truck does not read the ground or any give off any errors.

Once the testing is complete, epoxy the sensors into place. **DO NOT EPOXY THE SENSORS, ONLY THE HOUSINGS.** After the epoxy sets, plug the sensors back in using the configuration shown below. Failure to attach the harness in the recommended configuration could cause sensor issues.



Installation Instructions
2015 Chevy and GMC HD Rear Bumper
Product Number: E3050
Application: 2015+ Chevy and GMC HD Trucks

V. Maintenance/Care

- Periodically check and tighten all fasteners.
- Stripped, fractured, or bent bolts or nuts need to be replaced.



More than expected... Better than expected.