



FTS91004 2007 – 2008 GM 2500HD

Front CV Driveshaft for 8" Fabtech Lift System

Parts List

Qty	Part #	Description
1	FTS91004	Front CV Driveshaft
1	FT20381	Trans Shift Cable Bracket
2	FT91004i	Instruction Sheet

Tool List: (Not Included)

Assorted Metric and S.A.E Sockets & Allen Wrenches

Die Grinder w/ Cut-Off Wheel

READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION!

THIS DRIVESHAFT IS DESIGNED TO WORK ON 2007 – 2008 GM K2500HD DIESEL ENGINE MODEL TRUCKS EQUIPPED WITH A FABTECH 8" LIFT SYSTEM.

DRIVESHAFT WILL NOT WORK ON GM 1500HD TRUCKS OR 2500 SUV MODEL SUV's (2500 SUBURBAN / 2500 AVALANCHE).

INSTRUCTIONS:

1. Disconnect the negative terminal on the battery. Remove the front driveshaft and save the hardware. Locate the shift cable bracket. Remove the shift cable from the shift lever, then the factory shift cable bracket from the transmission. Next, remove transmission cooler lines from the bracket. Discard the bracket, save the hardware.
2. Locate FT20381 Shift Cable Bracket, mount the bracket to the transmission in the factory position with the factory hardware. Re-connect the trans cooler lines to the bracket, and the shift cable to the shift lever. SEE PHOTOS BELOW



3. Install the driveshaft into the t-case first and then attach the front differential with the factory hardware. Torque the bolts to 18 ft. lbs.