



FTS92003
FORD REAR DRIVE LINE SPACER

PARTS LIST:

Qua	Part #	Description
1	FT30072	Drive Line Spacer
4	12175451015	12mm-1.75 x 45mm Hex Bolt
4	50000005052	Flat Washer
2	FT92003i	Instruction Sheet
1	S-432	Box

TOOL LIST:

- Assorted Metric & Standard Wrenches
- Torque Wrench
- Measuring Tape

WARNING

When installing this rear drive shaft spacer you will need to measure the amount of slip on the rear drive shaft to the transmission. If there is not enough slip major transmission and driveline damage will occur.

When installing this rear drive shaft spacer Fabtech recommends a compress stop be installed to prevent drive shaft and trans mission damage.

1. Disconnect the negative terminal on the battery. Locate the 4 bolts attaching the rear drive shaft to the differential and remove. Discard the hardware. Place the drive shaft spacer between the drive shaft and the differential and attach using the supplied 12mm bolts and washer. SEE PHOTO BELOW.

