



**REPLACEMENT JOINT ASSEMBLY:**  
**FTS94009 (large joint)**

**Parts List:**

1	FT90033	Ball
2	FT71	Washer
2	FT70	Retaining Ring
1	FT1028	Bushing

**DO NOT ALTER THE FINISH OF THESE COMPONENTS, EXAMPLE- CHROMING, ZINC PLATING OR PAINTING. CHANGING THE FINISH CAN CAUSE STRUCTURAL FATIGUE OF COMPONENTS.**

**TOOL LIST: (NOT INCLUDED)**

- ASSORTED METRIC AND S.A.E SOCKETS, & WRENCHES
- SNAP RING PLIERS
- HYDROLOGIC PRESS

**READ ALL INSTRUCTIONS THOROUGHLY FROM START TO FINISH BEFORE BEGINNING INSTALLATION! IF THESE INSTRUCTIONS ARE NOT PROPERLY FOLLOWED, SEVERE FRAME, DRIVELINE AND / OR SUSPENSION DAMAGE MAY RESULT.**

1. Disconnect the negative terminal on the battery. Assemble the Urethane Pivot Joint as shown in the diagram below.

