



GB

Attention! Note installation position!

Insert control arm bush febi 10356 into the control arm from the back (see arrow for direction of travel) and pull in until the limit stop is reached. Position the bush in the control arm in such a way that the surface (arrow) and the centre weld form a 90° angle.