

## INSTALLATION INSTRUCTIONS


APPLICATION: 1997 - 2003 FORD F-150 TRUCK

1997 - 1999 FORD F-250 LD TRUCK

2004 FORD F-150 HERITAGE TRUCK

(EXCLUDES SUPER CREW AND FLARESIDE MODELS)

BUMPER KIT: 31002/32002



## PERFECT MATCH BUMPER

QTY	MOUNTING KIT CONTENTS	QTY	BUMPER KIT CONTENTS	TOOLS REQUIRED
4	1/2-13 X 1-1/2" CARRIAGE BOLT 1/2-13 HEX NUT 1/2" FLAT WASHER 1/2" SPLIT LOCK WASHER BOLT PLATE PLASTIC RETAINER	1	BUMPER LICENCE PLATE LIGHT KIT	3/4 SOCKET RATCHET TORQUE WRENCH WIRE CRIMPING TOOL


- STEP 1: Align bolt plates with mounting holes in the bumper (bolt plates go on the inside of the bumper hitch).


  Pass carriage bolts through the bolt plate and bumper hitch so that the bolts protrude from the bumper.

  Place plastic retainers on the carriage bolts to hold the assembly in place for ease of installation.

  Refer to Figure 1.
- STEP 2: Align bumper so the carriage bolts pass through the frame holes of the truck. Use the ½" washer, lock washer and hex nut to secure the bumper. Hand tighten hardware. Refer to Figure 1.
- STEP 3: Position bumper squarely to the tailgate and allow clearance for the tailgate to open. Using a torque wrench, tighten hardware to 60-65 ft-lbs.
- STEP 4: Use square plastic grommets and screws to install license plate. Refer to Figure 2.
- STEP 5: Install license plate lights into bumper. Splice light wires into truck wiring using supplied connectors. Ensure license plate lights are functioning properly. Refer to Figure 3.

ECO 1140 PAGE 1 OF 3








FIGURE 1 (PASSENGER SIDE VIEW)

ECO 1140 PAGE 2 OF 3




FIGURE 2




FIGURE 3

FEY AUTOMOTIVE PRODUCTS

Shop for other off-road bumpers on our website.

ECO 0724 PAGE 3 OF 3