


## INSTALLATION INSTRUCTIONS

APPLICATION: 1999 & UP CHEVY/GMC F/S TRUCK 1500/2500 LIGHT DUTY

> BUMPER KIT: 31006 32006


MOLINITING KIT CONTENTS			
1		MOUNTING KIT CONTENTS	
ITEM	QTY	DESCRIPTION	TOOLS REQUIRED
1	1	MOUNTING BRACKET, DRIVER SIDE, OUTER	9/16" SOCKET
2	1	MOUNTING BRACKET, DRIVER SIDE, INNER	
3	1	MOUNTING BRACKET, PASSENGER SIDE, OUTER	9/16" WRENCH
4	1	MOUNTING BRACKET, PASSENGER SIDE, INNER	22mm SOCKET
5 6	2 2	M14-2.0 X 40 HEX HEAD BOLT M14-2.0 HEX NUT	
7	4	M14-2.0 HEX NOT	22mm WRENCH
8	2	M14 PLIT LOCK WASHER	0/41 00 01/77
9	2	1/2-13 X 1.25 CARRIAGE SCREW	3/4" SOCKET
10	8	1/2-13 X 1.5 HEX HEAD BOLT	3/4" WRENCH
11	10	1/2" SPLIT LOCK WASHER	
12	12	1/2" FLAT WASHER	RATCHET
13	12		
14	2		TORQUE WRENCH
15 16	2 4	3/8-16 HEX NUT 3/8" FLAT WASHER	WIRE CRIMPING TOOL
17	4 2	3/8" LOCK WASHER	
BUMPER KIT CONTENTS   QTY DESCRIPTION   1 BUMPER   1 LICENSE PLATE MOUNT / LIGHT KIT #887153			



STEP 3: Install bumper onto mounting brackets with inner brackets inside of bumper hitch. Use remaining 1/2 inch hardware. DO NOT TIGHTEN. See Figure 3, 4 and Detail A.

STEP 4: Position bumper squarely to tailgate and allow clearance for tailgate to open. Tighten hardware as follows:

- · 3/8 inch to 35-40 ft lbs
- · 1/2 inch to 60-65 ft lbs
- · M14 to 70-80 ft lbs






FIGURE 3

