

## GS900 Series – Summer Bug Screen

### INSTALLATION INSTRUCTIONS


**Before installing Stick A Stud™ \*D\* fasteners, please note:**

- Clean area with isopropyl alcohol swab (supplied)
- Surface must be completely dry, wax free with no cleaning fluid present.
- For best results, install at temperatures over 60°F (16°C). Ensure that the surface of the vehicle is warm to the touch. Use a hair dryer to warm up the surface and the Stick A Stud™ \*D\* if necessary.
- The base of the Stick A Stud™ \*D\* can be shaped by bending or folding along the indented lines

#### FOR CONCAVE OR CONVEX SURFACES



#### FOR ANGLED SURFACES



- In some instances the Stick A Stud™ \*D\* fastener's base may require trimming. Simply cut as required



#### INSTALLATION:

- 1) Snap all Stick A Stud™ \*D\* fasteners to the bug screen while ensuring the protective backings remain intact.
- 2) Position the bug screen on the vehicle and note where each Stick A Stud™ \*D\* fastener will be located to ensure there will be maximum surface contact at each installation point.
- 3) Temporarily fasten the bug screen with masking tape to the vehicle.
- 4) Remove protective backing from a corner Stick A Stud™ \*D\*. Avoid touching adhesive.
- 5) Apply firm pressure for 10 seconds.
- 6) Apply the next Stick A Stud™ \*D\* fastener ensuring that no stress is applied to other fasteners when installing the bug screen. **CAUTION: A MINIMAL AMOUNT OF STRESS ON THE BUG SCREEN FROM SIDE TO SIDE AND TOP TO BOTTOM IS RECOMMENDED. EXCESSIVE STRESS WILL CAUSE IMPROPER INSTALLATION.**
- 7) Attach remaining Stick A Stud™ \*D\* fasteners along top and bottom.
- 8) Carefully remove bug screen and again apply firm pressure to each Stick A Stud™ \*D\* fastener. **INSTANT BOND CAN BE INCREASED BY USING HAIR DRYER ON HIGH FOR 2-3 MINUTES ON EACH INSTALLED STUD.**
- 9) Allow a minimum of 24 hours before use. See chart on reverse.



Peel away Stick-a-Stud™ fasteners protective backing



Adhere Stick-a-Stud™ fasteners to vehicle



Snap on Winter Front or Bug Screen

## BOND STRENGTH

| TIME       | BOND |
|------------|------|
| 20 minutes | 50%  |
| 60 minutes | 75%  |
| 24 hours   | 90%  |
| 72 hours   | 100% |

Additional Stick A Stud™ \*D\* fasteners are available; part number HK104  
They are also available in white; part number HK104-WHITE  
Kits with studs and screws are also available; part number HK103

### NOTES

- Models requiring adhesive hook and loop fastener installation:

Step 1 -BEFORE APPLYING HOOK AND LOOP FASTENER:

- Ensure the area where hook and loop fastener strips are to be attached is clean and dry.
- Remove protective backing
- Secure in place by pressing firmly on hook and loop fastener

Step 2 - : Attach adhesive backed hook and loop fastener strip to the underside of the grill frame to line up with hook and loop fastener on bug screen. On some vehicles the adhesive backed hook and loop fastener strips require mounting on the front of the grill frame or under the hood on the radiator frame.

- Models requiring attachment to grill face and bumper for installation:

GS901-24, GS904-6, GS906-7, GS907-3, GS907-34, GS909-34, GS909-48

- Models requiring attachment to the top of the grill frame under the hood and to the bumper: GS905-7, GS907-32, GS907-33, GS909-45

- Models requiring attachment to the hood: GS901-17, GS901-19, GS901-20, , GS901-21, GS901-27, GS903-4, GS905-42, GS909-281, GS909-46

- Models requiring attachment to grill face and to top of the grill frame under the hood: GS901-15, GS901-16, GS901-22, GS902-9, GS904-11, GS904-12, GS904-7, GS904-8, GS905-6, GS905-71, GS906-81, GS906-9, GS907-4, GS908-2, GS909-22, GS909-26, GS909-361, GS909-42, GS909-43

- On some models there are more domes than are required for installation. Align unit with grill to determine which domes are required.