



FAQ

Q I have a 2003 chevy silverado with extended cab and 6 bed. Do you have pre-bent lines from the ABS sensor to the driverside rear axel?

A This line set rite here is the 2 lines sitting on your axle. They go from the T-block on the drivers side axle tube to the left and right caliper hose.

Rely only on high-grade replacement brake parts offered on our virtual shelves.