



FAQ

Q Do you have to use a adaptor on these brake lines when installing on the factory threaded block on the axle. The one brake likes have different size fittings that thread into the block.

A It all depends on what size your rear brake shoes are. If you have the 3" rear shoes these are the correct lines. If you have 2.5" rear shoes you will need part# TRA9642SS. The fittings are different between the 2 sets. You should not have to use any adapters.

Rely only on high-grade replacement brake parts offered on our virtual shelves.