



Installation Instructions

.....

FIREWIRE ROCKER PANEL STROBE LIGHT INSTALLATION



1. Begin by installing your light into the bracket so that the wiring will be towards your power source. Wipe the Rocker Panel channel with the 3M wipe, remove the red tape from the back of the light, and stick your light into the channel. Be sure not to press too firmly with your fingertips so that you do not damage the light.
2. Next you will position your Rocker Panel onto the location desired. We recommend using the pinch weld on your vehicle as shown below. Determine where you want to mount the Rocker Panel with screws.



3. After you decide the locations to place the screws remove your Rocker Panel and begin drilling the necessary holes.



4. Now you need to simply mount the Rocker Panel onto your vehicle in the desired location with the mounting screws.



5. Run the wiring to your power source. Feel free to extend the wiring if needed.

6. Repeat to the other side of the vehicle and enjoy.



We at Firewire are proud to offer a high quality product at the industries most competitive pricing!

FIREWIRE

Shop for other accessory lighting on our website.