



* LIGHT BAR AND CUBE LIGHTS NOT INCLUDED

REQUIRED TOOLS

T-40 wrench

KIT CONTAINS

Gaskets (pre-attached to bracket)
Driver Bracket
Passenger Bracket

QTY

2
1
1

Ensure light bar is 52" mount to mount

Fishbone Offroad's light bar bracket is designed to fit light bars that are 52" between the mounting locations on the light bar. This means a 50" light bar will not fit without spacers (not included).

1) REMOVE FACTORY HARDWARE

Remove the upper five (5) factory bolts on your windshield mount bracket using a T-40 wrench.

2) INSTALL LIGHT BRACKET

Ensure the light bracket has the foam backing pre-installed. Place the bracket against the vehicle and **LOOSELY** secure using your factory hardware. This will make it easier to install your light bar.

3) REPEAT STEPS 1 AND 2 FOR OPPOSITE SIDE

4) INSTALL LIGHT BAR

Follow your light bar's instructions on how to mount the light. Once the light bar is securely mounted to

the brackets, tighten your factory hardware on both sides.

