

INSTALLATION INSTRUCTIONS

PART No.

FB21078

**Jeep® CJ/YJ/TJ Wrangler
Foot Peg (Set)**



REQUIRED TOOLS

Socket Set

KIT CONTAINS


Nylon Hex Nut
Flat Washer

QTY

2
2

1) REMOVE AND STORE YOUR FRONT DOORS

Remove the bolt or nut from the bottom of each door hinge.



NOTE

Penetrating oil may be useful in the next step. We also recommend rolling the windows down before the door removal. This will give you more room to hold the door, and will keep the window safe during storage.



Lift your door straight up to remove the pins from the hinges. You may need to rock the door back and forth to get it to lift out. Store your doors in a safe place against a blanket or cardboard to protect the paint.

2) INSTALL YOUR FOOT PEGS

Insert the shaft of the foot peg into your factory door hinges. Using the supplied hardware and a 13mm socket, secure the foot pegs in place.

3) YOU'RE DONE! ENJOY THE SUNSHINE!