



INSTALLATION INSTRUCTIONS

PART No.

FB21094

**Fits Standard Fairleads
Winch Line “Fishhook”**



REQUIRED TOOLS

5/16" Allen Wrench
11/16" Wrench

KIT CONTAINS

Winch Line “Fishhook”
M10 Socket Head Screw
3/8" Lock Washer
M10 Hex Nut
3/8" Flat Washer

QTY

1
2
2
2
2

1. PREPARE

Remove any fairleads currently installed on your bumper. If needed, disconnect your winch hook.



2. INSTALL



Slide your synthetic rope through the Fishhook's cable slot followed by your winch's fairlead.



INSTALLATION INSTRUCTIONS

PART No.

FB21094

**Fits Standard Fairleads
Winch Line “Fishhook”**



Holding the two parts together, place them up to your bumper and into place using the two included bolts lead by a flat washer.



With a 5/16” Allen wrench or hex bit socket and an 11/16” wrench, secure the Fishhook with a lock washer, followed by a nut.

3. FINALIZE

Wrap the excess synthetic rope around the rope support and resecure your winch hook.



Enjoy your Fishbone Offroad Winch Line “Fishhook”!