

FISHBONE  
OFFROAD



## INSTALLATION INSTRUCTIONS

**PART No.**

**FB21260**

**Fishbone Offroad  
Stainless Steel Tie-Down Kit**



### REQUIRED TOOLS

19MM Wrench

### KIT CONTAINS

(Fig. 1) M12 SS Bolt  
(Fig. 2) M12 SS Washer  
(Fig. 3) M12 SS Lock Washer  
(Fig. 4) M12 SS Eye-Nut

### QTY

4 ea  
8 ea  
4 ea  
4 ea



# INSTALLATION INSTRUCTIONS

**PART No.**

**FB21260**

**Fishbone Offroad  
Stainless Steel Tie-Down Kit**

**1) WARNING! USE THE TIE-DOWN KITS AT YOUR OWN DISCRETION.**

These are not to be used for any structural components, these are not lift points, nor recovery points. Use at your own discretion.

**2) APPLICATIONS**

These kits were designed to help aid securing down items to your vehicles. These fit locations where a ½" hole is such as on the parts below:

Fishbone Bed Racks  
Fishbone Storage Racks  
Fishbone Tub Rail Tie-Downs  
Fishbone In-Bed Tire Carrier

**3) INSTALL**

Find a suitable ½" Hole location where this tie down kit is desired to be installed, place a lock washer and then a normal washer onto the bolt, place bolt through hole, place the additional washer on top of mounting surface and lastly thread the eye-nut in place. Thread Locker is recommended for vibration resistance.