

FISHBONE  
OFFROAD



## INSTALLATION INSTRUCTIONS

**PART No.**

**FB21273**

**Universal for Utility Racks  
Hi-Lift Jack Mount Kit**



### REQUIRED TOOLS

3/4 Wrench

### KIT CONTAINS

Spacer 1/2"

Spacer 1"

Spacer 1.5"

M12-1.75 x 100MM Bolt

M12-1.75 x 110MM Bolt with Hole

M12 Split Lock Washer

M12 Flat Washer

Knobs

### QTY

1

1

1

1

1

2

2

2



## INSTALLATION INSTRUCTIONS

**PART No.**

**FB21273**

**Universal for Utility Racks**

**Hi-Lift Jack Mount Kit**

**1) MEASURE**

Fit Install the supplied M12 bolt (without hole) and flat washer onto the passenger side of your bed rack.



**2) ALIGN**

Install the 1" spacer onto the bolt followed by a lock washer and nut.



**3) INSTALL**

Repeat the previous steps on the drivers side using the 1.5" spacer.

**4) INSTALL TOOL**

Install Your Hi-Lift Jack with the bottom of the jack on the drivers side of the vehicle followed by the 1/2" spacer on the drivers side.



**5) TEST**

Install both threaded knobs to secure your Hi-Lift Jack to your bed rack.



## **INSTALLATION INSTRUCTIONS**

**PART No.** FB21273  
**Universal for Utility Racks**  
**Hi-Lift Jack Mount Kit**



Discover other roof racks and cargo carriers on our website.