



# INSTALLATION INSTRUCTIONS

**PART No.**

**FB21291**

**Toyota® 2005+ Tacoma  
Bed Rail RotopaX Mount**



## REQUIRED TOOLS

19mm Socket

-Tools for your RotopaX  
bracket

## KIT CONTAINS

Bed Rail RotopaX Mount  
M12 Hex Bolt  
M12 Flat Washer  
M12 Lock Washer  
T-Nut

## QTY

1  
1  
1  
1  
1

## Toyota® 2005+ Tacoma Bed Rail RotopaX Mount

### 1) PREPARE YOUR BED

Open your bed and decide where you would like to install your container, while considering its clearance with the rest of the vehicle.



Remove the trail rail cap and insert the included T-Nut into it. Slide it to your desired location.



### 2) PREPARE THE MOUNT

Place your RotopaX bracket onto the mount and install it according to its instructions.



### 3) INSTALL THE MOUNT

Begin installing your mount into the T-Nut using the included bolt and washers, with a 19mm socket.



Install your container according to its instructions.



### 4) ENJOY YOUR BED RAIL ROTOPAX MOUNT