



INSTALLATION INSTRUCTIONS

PART No. FB23144R & FB33145R

**Jeep® JT Gladiator
JT Rear Elite Fenders**



REQUIRED TOOLS

5mm Allen

KIT CONTAINS

Rear Fender (Left & Right)

Rubber Seal

M8 Button Head Bolt

M8 Flat Washer

M8 Serrated Nut

QTY

2

2

18

18

18

Note: These instructions will **NOT** cover how to remove factory fenders or inner fenders, and will **NOT** cover how to install inner fenders.

INSTALLATION INSTRUCTIONS

PART No. FB23144R & FB33145R

**Jeep® JT Gladiator
JT Rear Elite Fenders**

1) REMOVE

Begin by removing any inner and outer fenders your vehicle currently has installed.

2) PREPARE

The included rubber seals are driver and passenger side specific. Identify which side which is which by the bolt hole indents in the rubber. Peel off the backing and carefully apply the seal to the vehicle side wall of each fender.



3) INSTALL REAR FENDERS

Hold the corresponding fender up to the body and begin loosely securing it with 9 of the included M8 bolts, 9 washers, and 9 serrated nuts.



With a 5mm Allen key, tighten down the bolts.



Repeat on the opposite side.

4) ENJOY YOUR NEW FISHBONE OFFROAD REAR JT FENDERS