



INSTALLATION INSTRUCTIONS

PART No.

FB25081

**Jeep® JK 4DR* Wrangler
Wheel Well Storage Bins**



REQUIRED TOOLS

T-40 Torx

KIT CONTAINS

Storage bins (Left and Right)
Quick install knobs
Washers
Nuts (for soft-tops only)

QTY

1 ea
4
8
4

There are three (3) installation methods depending on your Jeep's current configuration. Please follow the instructions accordingly:

- A. Hard top with top on
- B. Hard top with top off
- C. Soft top* – with top up or down

*** NOTE: Soft top Jeeps did not come from the factory with the hard top nut with clip. This configuration will need to use the supplied extra four (4) washers and four (4) nuts to complete installation.**

A. FOR HARD TOP MODELS WITH TOP ON:

1) **UNBOLT YOUR HARD TOP**

Begin by removing your Freedom top. This will give you access to the two T-40 torx bolts for the hard top. Remove both upper T-40 torx bolts.



Remove the remaining six (6) torx bolts (3 on each side) from either side of the hard top from inside the Jeep.

*** WILL NOT FIT 2DR MODELS**

Jeep® JK 4DR* Wrangler Wheel Well Storage Bins



C. FOR SOFT TOP MODELS

1) **INSTALL STORAGE BINS**

With or without the soft top on (or down), simply place the storage bins on top of the Jeep tub and align above the factory holes.

Using the supplied four (4) knobs, eight (8) washers, and four (4) nuts, securely fasten the storage bins in place.

2) **INSTALL STORAGE BINS**

Lift the hard top just enough to slide a storage bin into place between the hard top and the Jeep body. Help from a friend is advised.



Either using all of your OEM hardware, or the supplied four (4) knobs and washers, secure the storage bins in place. Reuse your factory hardware to finish securing your hard top.

NOTE: Hard top Jeeps will not use the supplied nuts, and only four (4) of the washers.

B. FOR HARD TOP MODELS WITH TOP OFF:

1) **INSTALL STORAGE BINS**

With the top already off the Jeep, simply place the storage bins on top of the Jeep tub and align above the factory holes. Secure in place using the supplied knobs and washers and utilize the OEM hard top nut with clip.