REQUIRED TOOLS	KIT CONTAINS	QTY
T-40 Torx	Storage bins (Left and Right)	1 ea
	Quick install knobs	4
	Washers	4
	Allen Bolts	2

There are three (3) installation methods depending on your Jeep's current configuration. Please follow the instructions accordingly:

  A. Hard top with top on
  B. Hard top with top off
  C. Soft top* – with top up or down

A. FOR HARD TOP MODELS WITH TOP ON:

1) REMOVE HARDTOP BOLTS
Remove the two inner T-40 hardtop bolts on each side.

* WILL NOT FIT 2DOOR MODELS

2) INSTALL STORAGE BINS
Place storage bin either above or beneath hardtop lip.

Note: If your JL Model is equipped with the factory Subwoofer, the passenger side wheel well bin will not fit.

2510000

FISHBONE OFFROAD

INSTALLATION INSTRUCTIONS
PART No.
FB25100

Jeep® JL 4DR* Wrangler
Wheel Well Storage Bins

Either using all of your OEM hardware, or the supplied four (4) knobs and washers, secure the storage bins in place. Reuse your factory hardware to finish securing your hard top.

NOTE: Hard top Jeeps will not use the supplied bolts.

B. FOR HARD TOP MODELS WITH TOP OFF:
1) **INSTALL STORAGE BINS**
   With the top already off the Jeep, simply place the storage bins on top of the Jeep tub and align above the factory holes. Secure in place using the supplied knobs and washers and utilize the OEM hard top nut with clip.

C. FOR SOFT TOP MODELS
1) **INSTALL STORAGE BINS**
   With or without the soft top on (or down), pull back the carpet and screw in one of the supplied bolts into the OEM nut plate just below the plastic C-pillar.

2510000

Do so until 1 to 2 threads are visible.

Push the bin's bracket under the pillar and over the bolt threads until it sits evenly with the tub rail.

Secure the remaining bracket with either your OEM Torx bolt or one of the supplied quick knobs and washer.

Repeat on the opposite side.

ENJOY YOUR NEW FISHBONE OFFROAD STORAGE BINS!

2510000

Discover other car organizers on our website.