

INSTALLATION INSTRUCTIONS

PART No.

FB31044

**Jeep® CJ, YJ, TJ Wrangler
Fishbone Taillight Covers**



REQUIRED TOOLS

Phillips Screwdriver

KIT CONTAINS

Taillight Cover
No. 8 Screw
Spacer

QTY

2
8
8

1) REMOVE FACTORY HARDWARE

Using the screwdriver, remove all four (4) screws on the taillight.



2) MOUNT YOUR NEW TAILLIGHT COVERS

Using the supplied screws and spacers, install your new taillight cover. **DO NOT OVERTIGHTEN.** Ensure the spacer goes between your OEM taillight and the new taillight cover.



3) REPEAT STEPS 1 AND 2 FOR OPPOSITE SIDE

4) ENJOY YOUR NEW FISHBONE OFFROAD TAILLIGHT COVERS!