

MUFFLER #530513
REMOVAL & INSTALLATION DIAGRAM

CUT TAILPIPE HERE, JUST BEFORE THE 3 1/2" TAILPIPE REDUCES DOWN TO 3.00"

CUT BOTH INLET PIPES HERE, JUST IN FRONT OF THE INLET PIPE WELD.



STOCK MUFFLER

ONCE CUT, SLIDE MUFFLER #530513 FULLY ON. CLAMP OR FULLY WELD BOTH PIPES.



FLOWMASTER MUFFLER #530513

SLIDE ADAPTER PIPE #36036 INTO MUFFLER AND THEN SLIDE TAILPIPE INTO THE TOP END OF THE ADAPTER PIPE.

FLOWMASTER #36036

FLOWMASTER #36036