



Installation diagram for:
PIPE KIT #1050
1967-1969 CAMARO / FIREBIRD
3" PIPES

PACKING LIST		
<u>Qty</u>	<u>Description</u>	<u>Part #</u>
2	Front Pipe	26213
1	Midpipe (L)	26226
1	Midpipe (R)	26225
1	Tailpipe, Rear (L)	26228
1	Tailpipe, Rear (R)	26227
1	H-Pipe Stub	TB446
1	H-Pipe Stub	TB457

