



1997 - 2004 C5 Corvette
Axle-Back 2.5"
Exhaust System 11145FLT
Installation Instructions



Thank you for making FLOWTECH EXHAUST your choice in a high-performance exhaust system. Extensive dyno/track testing has enabled FLOWTECH to offer the most advanced design in exhaust systems. The installation, while not complex, will take a certain amount of time. However, the additional horsepower and improved performance will more than justify your efforts. Proper installation and maintenance will ensure long life and maximum performance from your FLOWTECH exhaust system.

BEFORE STARTING:

Your vehicle must be raised a minimum of 18-24 inches. A floor hoist is ideal. If no hoist is available, we strongly urge the use of axle stands as a safety measure.

CAUTION! WORK ONLY ON A LEVEL SURFACE. USE JACKS /JACKSTANDS OF SUFFICIENT CAPACITY TO LIFT AND SUPPORT YOUR VEHICLE. NEVER WORK UNDER A VEHICLE SUPPORTED BY A FLOOR OR BUMPER JACK.

INCLUDED HARDWARE:

Accessory Pack Contents:	
Qty.	Description
6	70mm Clamps
1	Instruction Sheet
4	5mm x 14mm Bolts
4	5mm Nut
2	2-Bolt Flange Gaskets

Parts List:	
Qty.	Description
1	Left Over-Axle Pipe
1	Right Over-Axle Pipe
1	Left Muffler Assembly
1	Right Muffler Assembly

Recommended Tools:
Spray Lube (WD 40®) or equivalent
3/8 Socket Wrench
12" 3/8 Drive Extension
13mm & 15mm Deep Socket
13mm Wrench
3/8 Universal
15mm & 18mm Socket
18mm Box Wrench

INSTALLATION:

IMPORTANT: Inspect your accessory pack: BEFORE YOU START!

1. Place the vehicle on flat a surface, set the parking brake, and block the front wheels.
2. **Disconnect the negative terminal of the battery.**
3. Lift the vehicle and support with jack stands.

WARNING! Never support a vehicle with a floor or bumper jack.

REMOVING THE OEM EXHAUST:

1. Spray the muffler isolators, muffler clamp bolts, and the H-Pipe flange nuts with WD-40® or equivalent.
2. Remove the (x2) nuts and (x2) bolts from the rear sway bar center mounting bushings. Do not remove the lower control arm bolt. Allow the sway bar assembly to swing down and away from the mufflers.
3. Loosen the clamps at the end of the H-Pipe where it connects to the muffler inlet pipes.
4. Remove the (x4) nuts at the H-Pipe where it connects to the catalytic converter down pipes. Remove the (x2) nuts at the center spring hangers. Slide the flanges off of the studs and remove the H-Pipe from the muffler inlet pipes.
5. Remove the (x2) bolts from the muffler hangers on each muffler and remove the muffler assembly from the car. Take note of the direction the isolators are installed on the hanger rods.

INSTALLATION OF YOUR FLOWTECH AXLE-BACK EXHAUST:

1. Inspect the exhaust hanger isolators and any OEM hardware to be reused. Replace, if necessary.
2. Install the sway bar.
3. Install the (x2) 70mm clamps on to the muffler inlet pipes with the bolts on the inside of the pipe and nut facing down.
4. Install the muffler isolators on to the Flowtech muffler hanger tabs in the same direction they were removed from the O.E.M mufflers.
5. Install the **Left** muffler into the car with the inlet pipe on top of the parking brake cable. Align the isolator assemblies. Install the isolator bolts. **NOTE:** Be sure the parking brake cable is routed under the exhaust pipe.
6. Install the **Right** muffler into the car with the inlet pipe on top of the parking brake cable. Align the isolator assemblies. Install the isolator bolts. **NOTE:** Be sure the parking brake cable is routed under the exhaust pipe.
7. Install the **Left** side over-axle pipe into the muffler. Install (x1) 70mm clamp and leave the clamp loose for now.
8. Install the **Right** side over-axle pipe into the muffler. Install (x1) 70mm clamp and leave the clamp loose for now.
9. Slide the H-pipe on to the over-axle pipes (spring hanger bracket facing up). Connect the H-Pipe to the catalytic converter down pipes, and install the supplied flange gaskets, bolts, and nuts. Tighten the flange nuts to allow for adjustment.
10. Tighten the clamps on the H-pipe where it connects to the over-axle pipes to allow for adjustment.

PLEASE NOTE: If purchasing FLOWTECH X-PIPE Part # **11144FLT** for this same application, the same installation instructions will apply the X-pipe as for the H-Pipe explained in steps 9 and 10.

11. Position the 70mm clamp at each muffler inlet pipe and tighten the (x2) clamps to allow for adjustment.
12. Tighten the clamps at the muffler isolators.
13. Check all the hardware and the connection points for proper installation and clearance.
14. Adjust and tighten all clamps and hardware starting at the front and working towards the tailpipes.
15. Remove the jack stands and lower the car.

16. Re-connect the battery and remove the wheel blocks.
17. Start the vehicle and check for leaks and loose hardware.
18. Check all hardware again after the first 150-200 miles of driving.



Enjoy your FLOWTECH Axle-Back Exhaust!