



**P/N 11143FLT (painted) & 31143FLT (ceramic coated)
2002-2013 Chevy/GMC SILVERADO/YUKON/TAHOE
1-7/8" Shorty Header 6.0L LS Engines (2 & 4WD)**

Thank you for making FLOWTECH HEADERS your choice in a high-performance exhaust system. Extensive dyno/track testing has enabled FLOWTECH to offer the most advanced design in exhaust systems. The installation, while not complex, will take a certain amount of time. However, the additional horsepower and improved performance will more than justify your efforts. Proper installation and maintenance will ensure long life and maximum performance from your FLOWTECH exhaust system.

Parts Included:

- Headers (**11143FLT** – Black Painted or **31143FLT** – Ceramic Coated)
- Header gaskets

Recommended Tools:

Flat Head Screwdriver	1/2" & 9/16" Wrench	15mm & 18mm Wrench
12mm, 15mm, & 18mm Socket	3/8" or 1/2" Ratchet	3/8" or 1/2" Swivel Socket Adapter
Oxygen Sensor Wrench	Jack	Jack Stands

BEFORE STARTING:

Your vehicle should be raised a minimum of 36 inches. A floor hoist is ideal. If no hoist is available, we strongly urge the use of axle stands as a safety measure.

CAUTION! YOUR CAR SHOULD NOT BE SUPPORTED ON A BUMPER JACK.

We recommend welding all pipe slip joints. If no welding equipment is available at the time of installation, use the furnished clamps to secure the pipes until they can be welded.

CAUTION! To avoid damage to the air bag system, do not rotate a disconnected steering shaft more than 180°.

INSTALLATION PROCEDURE – PLEASE READ CAREFULLY

1. Disconnect the battery cables from the battery to prevent electrical damage. Raise the front end for access to the exhaust manifold flanges. **DO NOT DEPEND ON A JACK!** Use jack stands and block the tires to safely support the vehicle.
2. Spray WD-40® or equivalent rust penetrating lubricant on all accessible fasteners and fittings before removing them.
3. Unbolt the flange nuts where the manifold connects to the exhaust system.

4. Disconnect the spark plug wires and remove the spark plugs to avoid any damage.
5. Remove the through-bolt from the steering shaft. Slip the shaft apart.
6. Disconnect the EGR tube from the right side exhaust manifold.
7. Remove the dipstick tube from the right side of the engine.
8. Unbolt the left and right side exhaust manifolds and remove from the vehicle.
9. Install the left and right header from above, using supplied the gaskets and hardware.
10. Reinstall the EGR tube and tighten all the bolts evenly to the manufacturer's torque specs.
11. Reinstall the dipstick tube and reconnect the steering shaft.
12. **RECHECK ALL OF YOUR WORK.**
13. Remove the vehicle from the jack stands.
14. Reconnect the battery cables, making sure all connections are secured.
15. Start the engine and allow to come to normal operating temperature. Check for leaks. Shut engine off and allow to cool down.
16. Recheck all connections to ensure they are secure.
17. Give the vehicle a test drive checking carefully for any new noises.
18. After several days of driving, check connections and re-tighten all bolts