



- 09-14 (Dual Exhaust 1500)  
With Sensors #100-40-9003**
- 09-14 (Dual Exhaust 1500)  
With Lights + Sensors Part #  
100-40-9004**
- 10-14 Dodge 1500-3500 with  
sensors Part #100-41-0003**
- 10-14 Dodge 1500-3500 With  
Lights + Sensors Part #100-  
41-0004**

Step 1: Remove OEM [factory bumper](#).

Step 2: Align Frontier bumper to end of frame. Install bolts through bracket and through truck frame. Install carriage bolts through drop plate and into factory hitch.

Step 3: If an impact is used, drive the bolt and hold the nut. To verify that the bolts are tight, check with a wrench by hand.

**Note:** Periodically check bolts to ensure that bolts remain tight. Also, before using with a trailer, check bolts to ensure that bolts are tight.

Bolt Bag Contents	
Quantity	Description
4	1/2" X 1-3/4" bolts
10	1/2" flat washers
6	1/2" Lock Washers
6	1/2" Hex nuts
2	1/4" X 1" bolts (license plate)
2	1/4" hex nuts (license plate)
2	5/8" flat washers
4	1/4" flat washers (license plate)
2	1/2" X 1 1/2" Carriage Bolt
2	1/4" lock washers (license plate)
4	Sensor Plugs
36	Total Pieces

**Warning: Do not tow from bumper. Only tow from OEM factory receiver.**