

HOW TO MEASURE THE CORRECT DROP



Measure the distance from the middle of your receiver to the ground & subtract 14" to determine the optimal drop for your truck.

**MIDDLE OF RECEIVER TO THE GROUND - 14" =
OPTIMAL DROP**