




INSTRUCTION MANUAL
CAT-BACK SINGLE EXHAUST
JEEP LIBERTY 3.7L 2/4WD 4DOOR
PART # 17206



ITEM	PART #	QTY	DESCRIPTION
A	701096	1	2-1/2" HEADPIPE
B	788500	1	SUPERFLOW MUFFLER
C	701097	1	2.5" TAILPIPE W/HANGER
D	500374	1	3.5" STAINLESS TIP
E	5757	3	2.5" CLAMP

INSTALLATION INSTRUCTIONS

PART #17206

WHEN INSTALLING THIS EXHAUST SYSTEM MAKE SURE TO USE PROPER SAFETY PRECAUTIONS. USE JACK STANDS WHEN UNDER TRUCK, SET PARKING BRAKE, BLOCK TIRES AND USE SAFETY GLASSES AND GLOVES.

DO NOT WORK WITH HOT PIPES!

SUGGESTED TOOLS:

HACKSAW, 9/16", 1/2", 15MM WRENCH & SOCKET, JACKSTANDS, WD-40

LAY OUT THE GIBSON EXHAUST ON THE FLOOR AND COMPARE PART #'S TO THE DRAWING.



REMOVE STOCK EXHAUST UNBOLT THE STOCK FLANGE LOCATED JUST BEHIND THE CATALYTIC CONVERTER. LEAVE ALL RUBBER GROMMETS IN PLACE. USE WD-40 TO AID IN THE REMOVAL OF EXHAUST AND HANGERS.



INSTALL HEADPIPE #A. UNTO STOCK FLANGE. DO NOT TIGHTEN.



INSTALL MUFFLER #B 1-1/2" TO 2" ONTO THE HEADPIPE WITH INLET FACING TOWARDS THE MOTOR. ROTATE THE MUFFLER UNTIL THE OUTLET IS AT THE 2 O'CLOCK POSITION. USE CLAMP #E TO SECURE THE MUFFLER TO THE HEADPIPE. MUFFLER INLET IS LOOKING INTO THE LOUVERS. DO NOT TIGHTEN.



INSTALL TAILPIPE #D INTO MUFFLER 1-1/2" TO 2". INSERT WELDED HANGER INTO RUBBER GROMMET. USE CLAMP #E TO SECURE TAILPIPE TO MUFFLER. ROTATE THE TAILPIPE UNTIL IT IS LEVEL.



INSTALL THE STAINLESS STEEL TIP. TO CLEAN TIP USE A SCOTCH BRITE PAD AND ANY STAINLESS OR ALUMINUM CLEANER. NOW GO BACK AND TIGHTEN ALL CLAMPS, NUTS AND BOLTS STARTING FROM THE FRONT AND WORKING BACK.

"MAKE SURE YOU HAVE A MINIMUM OF A 1" CLEARANCE ON ALL PIPES FROM ALL RUBBER BRAKE LINES, TIRES, SHOCKS, FUEL LINES, ETC."