



Installation Instructions

Axle-Back Exhaust System
Dodge Durango 5.7L Awd

Part #316006



ITEM	PART	QUANTITY	DESCRIPTION
A	701172	1	2.25" Driver Side Muffler Assembly
B	701173	1	2.25" Passenger Side Muffler Assembly
C	5756	2	2.25" Clamp

Installation Instructions #316006

When installing this exhaust system make sure to use proper safety precautions. Use jack stands when working under the vehicle, set parking brake, block tires and use safety glasses and gloves. Allow exhaust to cool before attempting installation. Severe injury or burns could occur if safety measures are not taken.

SUGGESTED TOOLS: 1/2", 9/16", 15mm wrenches & sockets, WD-40, hacksaw, jack stands

1. Disconnect the negative battery cable before removal of OEM exhaust. This will allow the computer to reset and recognize the new exhaust. Lay out the exhaust on the floor so it looks like the drawing and compare parts with manual.



2. To remove your stock exhaust:
Drivers Side: measure 9" down the pipe from the back of the muffler. You will be removing the factory hanger.



3. Next install your driver and passenger side muffler assembly's. Insert welded hangers into rubber grommets adjust assembly's. Use clamps #C to secure



Passenger side: measure 12" down the pipe from the back of the muffler.



GIBSON EXHAUST systems are designed on a factory stock vehicle. Any aftermarket products installed could increase the sound levels of the exhaust. **Make sure there is a 1" clearance from ALL rubber brake lines, shock boots, lines, tires, etc. to prevent heat related damage or fire.**