

Exhaust Tip

Parts List: x1 Exhaust Tip x1 Clamp



Required Tools (not included):

- A. Ratchet
- B. 15mm socket/wrench

Steps:

- 1. Clean exhaust pipe to ease the instalation.
- 2. Place the clamp on the narrow part of the tip (See picture above). Adjust it, do not tighten yet.
- 3. Place the exhaust tip over the pipe.
- 4. Tighten the nut with a 15mm socket/wrench to 40Lb/ft (55 N/m).
- 5. Revise periodically and re-tighten if necessary.

