

## DIRECTIONS



- 1. Protect Work Area From Spills**
- 2. Clean and Dry Surfaces to Be Bonded**
- 3. Apply Gorilla Super Glue**

Apply a small amount of Gorilla® Super Glue to one surface. Excess glue can cause delayed or failed bond. One drop covers one square inch.

To use nozzle, unscrew upper cap and remove. To use brush, unscrew full cap and wipe the brush on the inner rim of the bottle to remove excess glue.

- 4. Secure**

Press two surfaces together for 10-45 seconds to achieve bond. Note that gaps and uneven surfaces may cause delayed bonding.

Rely on premium automotive chemicals by Gorilla if you're looking for quality and efficiency.