

DIRECTIONS



1. Protect Work Area From Spills

2. Clean and Dry Surfaces to Be Bonded

3. Apply Gorilla Super Glue

Apply a small amount of Gorilla® Super Glue to one surface. Excess glue can cause delayed or failed bond. One drop of super glue covers one square inch.

4. Secure

Press two surfaces together for 10-45 seconds to achieve bond. Note that gaps and uneven surfaces may cause delayed bonding.

Rely on [premium automotive chemicals](#) by [Gorilla](#) if you're looking for quality and efficiency.