



## 1997-04 C5 Corvette Bumper Savers Installation Instructions (Read Carefully Before Starting Project)

Thank you for your purchase of the Granatelli Motor Sports Corvette '97-'04 C5 Corvette Nose Saver / Bumper Savers. Extensive testing has been performed on these parts and we feel you cannot get a better part in terms of quality or workmanship.

Tool Requirements: 11/32 drill bit, ½ socket, and ¼ drive ratchet or equivalent, ½ wrench – or (2) ½” wrenches.

1. Jack up the front of your Corvette and place jack stands (horses) in safe locations under under-carriage so that you can safely work around the lower radiator support area of the car.
2. Placing one bumper saver as high as possible up against the bottom on the urethane and touching the inside of the lower radiator support, use the 5/16 hole in the Bumper Saver as an index to mark the spot for your 11/32 hole.
3. Bumper Savers are to be mounted to both insides of the lower radiator support arms so repeat this step on the other side (inside of support on left and right) as well.
4. Drill 11/32 hole through lower radiator support arms as specified above in #2.
5. Press completed assemblies with 5/16 bolts through holes as shown in picture and tighten bolts to compression.



6. You're ready! – The front of your Corvette will love you forever.